



## Application method

# Re-oiling (film forming) with Kiehl-Eco-Refresher

Before applying Kiehl-Eco-Refresher, the surfaces must be properly prepared by dry cleaning.



### Step 1: Weather and general information

High levels of air humidity: Longer drying time!



Air humidity too low and temperatures too high: Drying time too short!

Avoid draughts! Switch off air conditioning and underfloor heating.



### Step 2: Devices for applying the oil

Flat mop, waxer, sponge clamp or special application tools. Moisten the clean mop cover, wring out and shake off excess moisture.



### Step 3: Apply oil

Shake the canister well and pour approx. 250 ml of the oil onto the floor. To pour the product without dripping, simply hold the canister at an angle. Always keep a cloth to hand to wipe up drips.

*Tip!*

*Always work towards the door and never away from it!  
Always use the product wet on wet!*



### Step 4: Drying time

Leave the oil to dry for approx. 2 hours, depending on the weather. Only then apply the next layers, as described under 3. During the drying time, keep the mops in a plastic bag to prevent them from drying out.



The safety advice and instructions for use on the containers, the product information and the safety data sheet must be observed. Please also observe the cleaning and maintenance recommendations of the manufacturers as well as the instruction manual of the machines and equipment used.



## Application method

# Re-oiling (film forming) with Kiehl-Eco-Refresher



## Step 5: Clean the devices

Clean the application tools with a damp cloth. Rinse the mops with clear water and then wash in the washing machine.



The safety advice and instructions for use on the containers, the product information and the safety data sheet must be observed. Please also observe the cleaning and maintenance recommendations of the manufacturers as well as the instruction manual of the machines and equipment used.