

Gommasol

Rubber streak remover

- ▲ Solvent-based special cleaner for removing rubber streaks and abraded rubber from industrial floorings
- ▲ High cleaning power
- ▲ Low-odour
- ▲ Easy to use



Area of application

Can be used on solvent-resistant floorings. Not suitable on surfaces sensitive to solvents, e.g. floors containing asphalt and bitumen as well as plastic surfaces (e.g. PVC).

Application

Please test on a small inconspicuous spot before first application. Adjacent areas and objects must be protected.

Rubber streak removal:

Pour the product (undiluted or diluted 1:1 to 1:2 with water) in a suitable spray unit with foam nozzle and distribute, leave for approx. 10 minutes to react. For normal soiling or local use, the dirty solution can be removed by mechanical wet cleaning with a scrubber drier and 1% Dopomat-forte solution as part of routine cleaning.

Basic cleaning (mechanical wet cleaning):

In case of very heavy soiling or use on a large area, spray product on the floor and then scrub thoroughly using a single disc machine and green pad. Then vacuum up the dirty solution. Remove product residue with a 1% solution of Dopomat-forte.

Suitable application tools: VFK260050 Funnel shaped spray bottle, VVK910330R Foam nozzle PCR, z205018 Spray bottle 1.5 L (red, PP foam nozzle, EPDM seal), z205051 PUMAS EPDM pressurized sprayer 5 L.



Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only!

Ingredients (according to 648/2004/EC)

Nonionic surfactants 5–15%, water-soluble solvents, additives.
pH value (concentrate): approx. 6

pH value (ready-to-use solution): approx. 7

Classification

Classification (in concentrate): GHS05, GHS07, Danger. H302 Harmful if swallowed. H318 Causes serious eye damage. H335 May cause respiratory irritation. P271 Use only outdoors or in a well-ventilated area. P280 Wear eye protection. P301+P330+P331 IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Contains: Phenoxyethanol (INCI)

Art. No.	Packaging unit (PU)	Numbers of PU per pallet
j050715	5 L canister	60