

# Coffexano-clean-Tab2

## Coffee machine cleaner

- ▲ Removes coffee oil, coffee grease, tanning agents and coffee residue in coffee machines and Thermos flasks
- ▲ Regular use prevents deposits, such as rancid coffee residue, which has a negative effect on the flavour of drinks
- ▲ Helps retain the value of the coffee machine
- ▲ Protects the material
- ▲ Free of fragrances and dyes



### Area of application

For automated coffee machines, portafilter coffee machines, filter coffee machines, espresso machines, as well as coffee, tea and Thermos flasks made by WMF, Saeco, DeLonghi, AEG, Melitta, Bosch, Franke, Jura, Krups, Miele, Siemens, Solis and many more. Do not use on alkali-sensitive surfaces and components.

### Application

Please test on a small inconspicuous spot before first application. Consult the manufacturer's operating instructions. After cleaning, rinse the respective parts well with drinking water.

### Cleaning coffee machines:

Observe the machine's cleaning instructions. Cleaning takes place in line with the machine's cleaning instructions. To clean coffee, tea and Thermos flasks: Fill flask with hot water, add one tablet, leave for 30 minutes to react and then rinse with drinking water. Consumption: 1.0 tab per wash cycle.

Surfaces and kitchen equipment that come into direct contact with food must be rinsed thoroughly with drinking water.

### Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only!

### Ingredients (according to 648/2004/EC)

Nonionic surfactants < 5%, oxygen-based bleaching agents > 30%, phosphonates < 5%, phosphates 15–30%.  
pH (1:100): approx. 10

### Classification

Classification (in concentrate): GHS05, Danger. H318 Causes serious eye damage. P280 Wear eye protection. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P337+P313 If eye irritation persists: Get medical advice/attention. P101 If medical advice is needed, have product container or label at hand. Contains: Sodium Carbonate Peroxide (INCI)

Art. No.	Packaging unit (PU)	Numbers of PU per pallet
j5516kg	Carton of 2 x 150 tabs (plastic boxes)	352