

Cellofit

Cleaner for photo cells

- ▲ Outstanding cleaning performance for common dirt on photo cells
- ▲ Very good at dissolving limescale and other inorganic dirt
- ▲ Protects the material on the surfaces in question
- ▲ Highly economical thanks to the very strong product concentration
- ▲ Free from EDTA, NTA and phosphates



Application

Product is not suitable for pre-dilution

Apply undiluted to the application with a suitable dosing device or use manually.

Intensive cleaner:

For the cleaning of photo cells as a spray application.

Leave for 1-3 minutes to take effect. If necessary, work fluid in with a cloth or non-abrasive sponge. Then rinse thoroughly with water.

Note

A change in colour and clouding may occur without any loss in quality due to the natural raw materials. Apply extensively to saturate the surface. Do not allow the cleaning solution to dry. No liability is accepted in case of incorrect and unprofessional use!

Ingredients (according to 648/2004/EC)

Nonionic surfactants < 5%, anionic surfactants < 5%, organic acids, water-soluble solvents, dyes, fragrances.
pH value (concentrate): approx. 2

Art. No.	Packaging unit (PU)	Numbers of PU per pallet
c642046	Carton of 6 x 500 ml funnel shaped bottles with sprayer	120