

# Kiehl-Legnodur-Titan

## Satin-matt 2-component permanent coating

- ▲ Varnish-like drying, plasticiser-free polyurethane emulsion polish
- ▲ Coat thickness up to 25 µm
- ▲ High chemical resistance, e.g. against hand disinfectants
- ▲ Outstanding film-forming properties
- ▲ Hard-wearing, easy to clean protective film
- ▲ Maintenance of the coating after dry cleaning
- ▲ The film cannot be removed by wet stripping



### Area of application

On real wood surfaces, which have been coated with wood oils or sealants. Also suitable for resilient floor surfaces and screed flooring which can be coated.

### Application

Please test on a small inconspicuous spot before first application. The surfaces must be clean, release-agent free and properly prepared to ensure faultless adhesion and appearance. Before application, Kiehl-Legnodur-Titan (1st component) must be mixed with the second component Kiehl-Durator. Shake immediately. Allow to rest for 5 minutes. The resulting 2-component coating can be used for 6 hours. Close canister immediately after use. Avoid draughts during use and drying.

### Preparation of the surface:

Dry clean parquet surfaces before coating (use Kiehl-Woodmaster-Pad-Fine). Resilient floor coverings must be stripped (Veroclean, 3 L to 8 L of water). Resilient floorings already coated with Kiehl-Legnodur must be dry cleaned using a Kiehl-Woodmaster-Pad-Fine. Accruing dust must be removed.

### Coating:

Depending on the absorbency of the surface, 2–3 layers at intervals of approx. 90 minutes.

After preparing the surfaces, apply a thin coat of undiluted product to the clean floor using a flat mop or waxer. If necessary, carry out intermediate sanding using a Kiehl-Woodmaster-Pad-Fine after applying the first layer. If there is more than 24 hours drying time between the applications, an intermediate sanding with Kiehl-Woodmaster-Pad-Fine must be carried out. Consumption: 30.0 ml/m<sup>2</sup> per application.



### Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only! Protect from frost.

### Ingredients

Synthetic dispersions, free from metal salts, polyethylene waxes, water-soluble solvents, preservatives.  
pH value (concentrate): approx. 8

Art. No.	Packaging unit (PU)	Numbers of PU per pallet
j2213115	Carton of 5 L PCR canister + 100 ml Kiehl-Durator	112