

Santex Intensive sanitary cleaner

- Phosphoric acid-based intensive sanitary cleaner
- Removes lime residues, limescale, urine scale and soap scum
- A fresh and intense fragrance during use





Area of application

Can be used on acid and water-resistant surfaces and objects in sanitary areas. Acid-sensitive surfaces, such as damaged chromium coatings on fittings, brass, anodised aluminium, polyamide and acid-sensitive natural and artificial stone, can be damaged by products containing acid.

Application

Please test on a small inconspicuous spot before first application. Always water joints and fittings beforehand with cold water. Rinse all treated surfaces with water.

Intensive cleaning (surface cleaning):

Apply the product undiluted or with a dilution ratio of up to 20 ml to 4 L of cold water, depending on the degree of soiling. Wet the surface with the product or cleaning solution and clean with a cleaning textile. For toilet bowls and urinals, spray the undiluted product under the rim, leave it to react for a short time, clean and flush with water. Consumption: 1.0– 5.0 ml/m².

Intensive cleaning (wiping):

Up to 40 ml to 8 L of cold water, depending on the degree of soiling. Wet the surface with cleaning solution and clean with a mop. Consumption: $1.0-3.0 \text{ ml/m}^2$.



Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only!

Ingredients (according to 648/2004/EC)

Nonionic surfactants < 5%, inorganic acids, organic acids, maintenance substances, corrosion protection, dyes, fragrances (Coumarin). pH value (concentrate): approx. 1 pH value (ready-to-use solution): approx. 2

Classification

Classification (in concentrate): GHS07, Warning. H319 Causes serious eye irritation. H315 Causes skin irritation. P280 Wear protective gloves/eye protection. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

Numbers of PU per pallet 84 2