

ARENAS-alcawash Liquid alkaline laundry detergent

- _____
- Phosphate-free, alkaline, concentrated detergent
 Excellent washing results at 30–90 °C
- Prevents premature greying of textiles
- Prevents premature greying of textiles
 Contains renewable plant-based raw materials
- RKI listed in combination with ARENAS-oxydes

AR	Е	Ν	A	S
	0	Ò	Έ	Х



Area of application

Suitable for washing coloured and white laundry, as well as cleaning textiles in the temperature range 30–90 °C. Not suitable for textiles made of wool and silk. For the thermochemical laundry disinfection of alkali-resistant, bleachable textiles in combination with ARENAS-oxydes.

Application

Separate the textiles to be washed based on colour and the wash temperatures given.

Washing textiles:

Dosage via dosing pumps

Recommended dosage for washing machines	light soiling	normal soiling	heavy soiling
Hardness level 1 (< 1.5 mmol/L)	0.3%	0.4%	0.5%
Hardness level 2 (1.5–2.5 mmol/L)	0.4%	0.5%	0.6%
Hardness level 3 (> 2.5 mmol/L)	0.5%	0.6%	0.8%

Attach the canister to the pump connection for the detergent. Dosage takes place automatically through the washing machine's program control. Consumption: 9.0–15.0 ml/kg of laundry.



Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only! You can find information about your local water hardness level from your local water supplier.

Ingredients (according to 648/2004/EC)

Nonionic surfactants 15–30%, amphoteric surfactants 5–15%, soap < 5%, alkalis, optical brighteners, fragrances. pH value (concentrate): > 13.5 pH value (ready-to-use solution): approx. 11

Classification

Classification (in concentrate): GHS05, Danger. H290 May be corrosive to metals. H314 Causes severe skin burns and eye damage. P280 Wear protective gloves/protective clothing/eye protection/face protection. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P308+P313 IF exposed or concerned: Get medical advice/attention. Contains: Potassium Hydroxide (INCI)

Art. No.	Packaging unit (PU)	Contents in kg	Numbers of PU per pallet
j652810	10 L canister	11.8	60
j652821	20 L canister	23.6	36